

Steps of loading the wire on to the machine

1. Set the wire running speed with 3 (the lowest speed is 3, and the highest speed is 0) on the computer as follows:

step 3 set wire speed 3

5 OK

step 2 click 1st line

step 1, right click on gray words > Click HF Power Setting

Manual: Pon 50.00us, Poff 8, Gon 1, Goff 0, Wire 0, LowVolt, VF 0, _/|_


HF Power Settings

www.bmnc.cn

2. Move the limited blocks to two ends.



3. Make the wire drum move to the following position:




4. Load wire on the wire drum as follows

Please note:


A. makes the roller side with the brand mark outside!

B. The rotating direction of the wire drum is forward!


C. Fix the wire end to the wire drum firstly (the wire drum side near to the motor!)



5. Arranging the wire on all pulleys as follow:



5. Fix the wire end on the right side of the drum.(make sure the wire on all pulleys and electrical blocks as follows:



6. Make the wire drum move to the position that we start to load the wire firstly, then reset the wire running speed with faster speed (1 or 0), tension the wire with the hand wheel manually. (Before tensioning the wire, please press the bottom switch to make sure the rotating direction is forward). When you tension the wire, please use the almost the same power, at the same time, pay more attention to the wire end. Stop drum when the wire near to the end.
7. After the first time tensioning, if the wire is still loose, please repeat tensioning 2 or 3 times.
8. When you finish the tensioning the wire, please fix the limited switch to make sure the wire drum move between the two limited ends.