

Hello, Friend,

1, if the machine can spark, please check the wire on table, please see following photo. This wire maybe break because of the workpiece fall. 80% is this wire, please check this carefully.



If above wire is not problem, please check following two wire.





2, If the machine can not spark, please let me know there has voltage or not, there has V meter in machine controller, please check that meter has voltage or not.

I will wait for your reply. By the way, my whatsapp 0086-15862331785 if you have any questions, send by whatsapp is more quick.

**Regards,
David gao.**